

RAIN AND SUN GUARD**DESCRIPTION**

The Model 40 is a PVC rain and sun guard designed for use with the Model 1100 Industrial Temperature Network Transmitter and the Model 1200 Industrial Temperature / Relative Humidity / Dew Point Network Transmitter. The guard is designed to keep rain off the end of the probe and prevent wetting of the humidity sensor within the model 1200. The guard will also keep direct sunlight from shining on the sensors of the probes. The rain guard is available in five-inch lengths to support a four-inch probe. The Model 40 features a screen to prevent the entry and nesting of insects.

INSTALLATION

The Model 40 has a ½ inch NPT thread on top. The probe is screwed into this thread and mounted with the open end of the tube facing down. Hand tightening is sufficient.



MODEL 40

ORDERING INFORMATION

40	Model 40 Rain Guard
-----------	----------------------------

Code	Options
-0	Basic Unit

Code	Probe Length
-04	4" Probe

40	-0	-04	Model 40 for four inch probe
-----------	-----------	------------	-------------------------------------



Rain Guard installed on Model 1200